

OUTDOOR POOL

EMERGENCY CONTACT:


Swim Clean

801-265-1707




Outdoor Pool

- Outdoor pool is located on the upper terrace behind the house.
- The electrical panel for the pool can be found in the pool room with a disconnect on the outside of the room.



Pool Shutoff

- Controls for shutting off the water to the pool are located in the pool room next to the rec room.
- The blue heat exchanger is directly in front of you when you walk in to the pool room. This is the source of heat for the pool water.
- The two shut off levers are located to the left of the blue heat exchanger. The levers are red.



Pool mechanics

- The mechanical controls, recirc pump, filter and valves for the pool are all located inside the pool room.
- The filter should be cleaned periodically depending upon amount of pool use.
- The pool mechanical system should be inspected yearly by Swim Clean.